

Silvaflame-Cleervue Co Ltd

DRILL GUARDS LRTS/LRTL/LRTXL

DESCRIPTION

This Cleervue Drill Guard is made of Aluminium with a Polycarbonate visor making it very impact resistant.

The smooth telescopic action of the guard protects the operator from contact with the spindle, drill chuck and cutting bit before, during and after the drilling operation.

The guard is easily opens to the left out of the way, allowing quick bit changes. Guards lock securely in place with a spring loaded pin.

Guards include a depth adjustment knob, allowing operator to adjust guard position, making drilling operation easier.

The guard comes in sizes 50mm – 104mm.

The guards all work in the same way with the only difference been the length in which they come down.

LRTS 3 section has a overall length of 265mm and a min length of 115mm.

LRTL 2 section has an overall length of 265mm and a min length of 155mm.

LRTXL 3 section guard has an overall length of 350mm and a min length of 165mm.

UNPACKING

Check for shipping damage. If damage has occurred, a claim must be filled with carrier. Check for completeness. Immediately report missing parts to supplier.

SAFETY RULES

Warning: for your own safety, read all of the instructions and precautions before operating tool.

Caution: always follow proper operating procedures as defined in this manual - even if you are familiar with use of this or similar tools.

Remember that being careless for even a fraction of a second can result in severe personal injury.

ASSEMBLY

The guard will come completely assembled ready to be fitted to your machine.

INSTALLATION

Place clamp opening over the bottom of the drill press quill and secure by tightening bolt at rear of clamp.

Important: Check to be sure the clamp is tight and will not slide or rotate on the quill.

Check visors daily before use for signs of cracking or weakening. Some coolants and cleaners and weaken polycarbonate so please check with your suppliers before use.

We advise replacing the visors every 3 years.

OPERATION

Lower guard will automatically slide into upper guard as drill press is operated. Be sure lower guard slides smoothly in and out of upper guard.

Lower guard position can be locked by tightening adjustment knob with lower guard in desired position.

Upper and lower guard assembly can be opened to the left out of the way for easy cutting bit changes.

Pull plunger pin out and pivot guard assembly up.

After changing bit and before operating drill press, be sure to close guard assembly with plunger seated securely in clamp.

SILVAFLAME
READY TO USE
POLYCARBONATE
CLEANER

See website for details



For additional technical information or spare parts - Please contact us, we will be happy to help

SILVAFLAME-CLEERVUE COMPANY LIMITED

22, Park Street, Bridgtown, Cannock, Staffordshire, WS11 0BX. UK

T: 01543 431060 F: 01543 509140

e-mail: enquiries@silvaflame.com / silvaflame@cleervue.com

Manufacturers of MACHINERY SAFETY GUARDS



British made for
over 70 years

