

Silvaflame-Cleervue Co Ltd

OPTIGUARDS

DESCRIPTION

The Cleervue Optiguards are made up of an on/off magnetic base with a choice of stems,

Both Models 01 and 05 have flexible stems, with the model 00-1 and 03 having a ball joint stem.

The guards come in a choice of two size visor 3mm x 245mm x 180mm or 3mm x 295mm x 280mm.

UNPACKING

Check for shipping damage. If damage has occurred, a claim must be filled with carrier. Check for completeness. Immediately report missing parts to supplier.

SAFETY RULES

Warning: for your own safety, read all the instructions and precautions before operating tool.

Caution: always follow proper operating procedures as defined in this manual - even if you are familiar with use of this or similar tools.

Remember that being careless for even a fraction of a second can result in severe personal injury.

ASSEMBLY

The guard will come completely assembled ready to be fitted to your machine.

INSTALLATION

The optiguard easily attaches to any ferromagnetic metals.

Important: Make sure all bolts are nice and tight.

The visors should be replaced every 3 years and should be checked every day before use for signs of cracking or weakening.

Some coolants and cleaners are known to weaken polycarbonate so please check with your supplier before use.

OPERATION


The Optiguard is a very simple yet effective guard great for jobs where flying swarf can be a problem.

The guard is a great extra on lathes millers and drillers.

The guard is easily move with the on/off feature.

SILVAFLAME
READY TO USE
POLYCARBONATE
CLEANER

See website for details



For additional technical information or spare parts - Please contact us, we will be happy to help

SILVAFLAME-CLEERVUE COMPANY LIMITED

22, Park Street, Bridgtown, Cannock, Staffordshire, WS11 0BX. UK

T: 01543 431060 F: 01543 509140

e-mail: enquiries@silvaflame.com / silvaflame@cleervue.com

Manufacturers of MACHINERY SAFETY GUARDS



British made for
over 70 years

